




# QUICK GUIDE DOUBLE HANDLE



## MOUNT YOUR GOPRO CAMERA

Use the thumb bolt originally included with your GoPro camera to mount your housing on the GoPro adapter.



**LANYARD  
HOLES**

**GOPRO MOUNT (INCLUDED)**  
**1/4-20 THREADED TRIPOD MOUNT**  
**1/4" SLOT FOR OTHER CAMERA TYPES**



### **INSTALLING LIGHT ARM BASES**

The top of each handle includes a 1/4-20 threaded hole for light arm bases. If you are installing a Backscatter Flex Arm, use a 3/16" hex key and 7/16" wrench to mount the base to the handle. Tighten well to prevent the arm from rotating.



### **INSTALLING FLEX ARMS AND LIGHTS**

- 1) Snap your light on to the flex arm.
- 2) Snap the flex arm on to the flex arm base.

**DISTRIBUTED BY:**

**BACKSCATTER • +1-831-645-1082 • [sales@backscatter.com](mailto:sales@backscatter.com)  
[www.backscatter.com](http://www.backscatter.com)**